



Experience every note in beautiful high-res detail with the Thore C150 Revolution headphones.


The pair provides rich immersive sound - bass is firm and weighted while the mids and highs are clear and vibrant with excellent detail.

Sink in to enjoy the comfort of protein leather ear cups bolstered with Allora memory foam.

Our bet? You'll never go back to earbuds.

We recommend taking a few moments to read through this guide and get to know all the great features your C150 Revolution has to offer.

Overview of Wireless Headphones



Charging

Connect charging cable to power source and to charging port on Headphones. (Charging port is on bottom of right earphone).

LED indicator will turn red during charging and turn off when fully charged. When charging while paired, the LED indicator will turn purple.

For optimal battery performance, fully charge for three hours before first use.

Headphone battery level will be visible on the connected device that supports this feature.

Power On

Press **⏻** for two seconds, an audio prompt will indicate that the Headphones have powered on.

Once powered on, the Headphones will attempt to connect with a previously paired device.

On first power on, and when Headphones do not detect a previously paired device, the Headphones will automatically enter pairing mode indicated by an audio prompt and the LED indicator flashing blue and red alternately (for pairing instructions, see the Pairing section, step 2).

Power Off

Press **⏻** for two seconds, a audio prompt will indicate that the Headphones have powered off.

Pairing

1. With Headphones powered off, press and hold **⏻** for three seconds, a audio prompt will indicate that the Headphones have entered pairing mode and the LED indicator will flash blue and red alternately.
2. Enable Bluetooth on mobile device (for detailed information, refer to the user manual of the mobile device).
3. On mobile device, select “C150” (the Headphones) in the pairing list, if prompted for a Password, (sometimes called a “Passkey”, or “PIN Number”) enter “0000” or “1234”.
4. A audio prompt will indicate that the Headphones and device have paired.

Note: Pairing mode will automatically be canceled after three minutes. To re-enter pairing mode, see pairing instructions.

Media and Phone Control

Volume: Press \oplus or \ominus until desired volume is reached.

Play and Pause: While media app is open on connected device, press \odot to Play or Pause.

Previous and Next: While media app is open on connected device, Press and hold \ll or \gg to navigate between tracks.

Answer Call: During incoming call, Press \odot once.

Reject Call: During incoming call, Press \odot twice.

Ending Call: During call, Press \odot .

Redial Last Number: Not during call, Press \odot twice.

Mobile devices and media apps can change the standard functionality of media and phone buttons. Please consult with Devices manufacture or app developer should functionality differ than described.

Using Headphones with a Wire

Connect audio cable to audio port on Headphones and to an audio source. (Connecting an audio cable to Headphones will automatically power off Headphones. Headphones operate in wired mode when powered off.)

Media and phone call control buttons only function when Headphones are in wireless mode or when using an audio cable that supports such functionality.

Battery Life

Talk: 5-7 Hours

Music: 3-7 Hours

Standby: 200 Hours

Full-charge: 2.5 Hours

LED Indicator

Blue and red flashing alternatelyPairing

Blue solidPaired

Blue flashing slowPlaying audio or Calling

Red solidCharging while power off

Purple solid.....Charging while paired

Specifications

Wireless BT Version: 4.1

Frequency: 2.402-2.480GHz

Support Mode: HFP A2DP AVRCP

Operating Range: Up to 10 meters (33 feet)

Battery Capacity: 185mAH

Safety Information

Do not expose to excessive heat, water or moisture.

Do not drop or disassemble.

Power off before placing in snug places such as handbag or suitcase.

When cleaning, use a soft cloth, if necessary dampened with a minimum amount of water or diluted mild soap.

Do not use any cleaning agents containing alcohol, ammonia, benzene, or abrasives.

Operate or store in a place where temperature is between -15°C (5°F) and 55°C (131°F) (up to 90% relative humidity).

Battery life may vary depending on climate.

To avoid hearing damage, limit use at high volume and set the volume to a safe level.

Using headphones with both ears covered while driving is not recommended and may be illegal in some areas.

Warranty

Your new Thore C150 Wireless Headphones is covered by a Limited Manufacturer's Warranty. Details of the warranty are as follows:

for a period of one (1) year from the date of retail purchase, Thore warrants that this product is free of any defects in manufacturing, materials and workmanship. During the warranty period, we shall, at our sole discretion, repair or replace any defective parts within a reasonable period of time and free of charge. Return shipping charges are excluded from warranty coverage.

FCC Compliant

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

Support

As with all Thore products, the Thore C150 Wireless Headphones is backed by our quality assurance and satisfaction guarantee. If you should experience any technical or performance issues with your device, or if you simply have a question or inquiry, we invite you to contact our customer service department at hello@ThoreAudio.com, and we will do everything we can to help resolve the issue.